



ENG
UA

Folding wardrobe Lukas Розпашна шафа Лукас


2400x1800x500 mm



To avoid falling

we recommend fixing the product to the wall using **corners** or **double-sided tape**

Щоб уникнути падіння виробу рекомендуємо закріпити його до стіни кутиками чи двосторонньою стрічкою.



T

ENG



UA

RULES FOR USE AND CARE OF FURNITURE

1. Use furniture only in dry rooms protected from the effects of weather conditions.
2. Install with suitable tools according to these assembly instructions.
3. Try to assemble as close to the location as possible.
4. The body is assembling in a horizontal position.
5. Before moving furniture, make sure that it is not loaded with items.

Caution: moving furniture may damage it.
When moving, hold on to vertical elements only; moving furniture by horizontal parts can break the product.

6. Overloading the furniture can damage it.
7. From time to time check the fittings and their correct position.
8. Wipe the furniture surface only with a slightly damp cloth or paper towels. Do not use chemical cleaning agents other than those specifically made for this.






ПРАВИЛА ВИКОРИСТАННЯ ТА ДОГЛЯДУ ЗА МЕБЛЯМИ


1. Використовуйте меблі тільки в сухих приміщеннях, захищених від впливу погодних умов.
2. Виконуйте установку за допомогою відповідних інструментів відповідно до даної інструкції зі складання.
3. Намагайтеся проводити збірку якомога ближче до місця використання.
4. Збірка корпусу здійснюється в горизонтальному положенні.
5. Перед переміщенням меблів переконайтеся, що вони не навантажені.

Увага: переміщення меблів може привести до її пошкодження.

При переміщенні тримайтеся тільки за вертикальні елементи, переміщаючи меблі за горизонтальні деталі ви можете зламати виріб.

6. Перевантаження меблів може привести до їх пошкодження.
7. Час від часу перевіряйте кріплення і правильність їх положення.
8. Протирайте поверхню меблів тільки добре віджатою вологою тканиною або ж паперовими рушниками. Не використовуйте хімічні засоби для очищення, крім спеціально для цього призначених.







№	size / розмір		pack / уп.	qty / к-ть
1	2400	500	1/4	1
2	2400	500	1/4	1
3	2350	447	1/4	4
4	1914	500	2/4	1
5	1768	500	2/4	3
6	392	500	2/4	1
7	1768	46	2/4	2

№	size / розмір		pack / уп.	qty / к-ть
8	400	46	2/4	1
9	450	160	2/4	2
10	450	160	2/4	2
11	876	500	3/4	1
12	875	420	3/4	4
13	896	235	3/4	2
14	832	447	3/4	2





№	size / розмір		pack / уп.	qty / к-ть
15	818	160	4/4	2
16	412	446	4/4	2
17	412	446	4/4	2
18	1934	446	4/4	1
19	1934	446	4/4	1
20	1454	446	4/4	1
21	1454	446	4/4	1

6x 	11x D	11x E	1x wr	2x n906	2x w5	2x w5
1x z1	30x φ7x50 mm e32	18x s2	22x φ8x30 mm f1	16x φ5x17 mm d1	103x φ3,5x16 mm p38	11x c3
9x l1	 l1	2x 40x40x15 mm n14	8x φ15x12mm #16 r1	8x 20/9 r16	8x s2	12x 15x10x14mm c14
10x k1	44x φ6x13 mm e3	16x φ6x8 mm e31				





1








2











3











4



5



6



ENG








The dowels are not included.
Purchase separately.

UA

Дюбелі в комплект не входять.
Необхідно придбати окремо.





7

x2





8

x2



9
x2



10

