








Instalation manual

ALEX: Chest




Element symbol	Dimensions			Code	Package
	838	354	16		
1	838	354	16	A-101	1/1
2	838	354	16	A-102	1/1
3	840	355	16	A-201	1/1
4	840	355	16	A-202	1/1
5	806	326	16	A-301	1/1
6	806	326	16	A-302	1/1
7	749	100	16	A-501	1/1
8	749	100	16	A-502	1/1
9	320	100	16	A-503	1/1
10	320	100	16	A-504	1/1
11	140	800	16	A-001	1/1
12	689	399	16	A-002	1/1
13	689	399	16	A-003	1/1
14	856	412	3	A-601	1/1
15	763	302	3	A-602	1/1


1x	8x	8x	1x	40x	4x	4x	1x
p17	s1	s2	f3	l1	k43	p26	
φ5x60 mm	φ16		φ10x60 mm		48 (8mm)	φ4x35 mm	
1x	8x	8x	2x	22x	1x	1x	1x
p17	r1	r16	p21	p25	z1	n14	
φ5x60 mm	φ15x12mm #16		φ4x30mm	φ3.5x16 mm			
1x	4x	4x	8x	16x	f1	1x	1x
L 100mm	b119	d1	φ7x50 mm	φ8x50 mm		GLUE 50g	




1




3




2




4




5




7





6



8



9



10

