








Installation manual

ALEX: Chest




Element symbol	Dimensions	Code	Package
1	358 354 16	A-114	1/1
2	358 354 16	A-115	1/1
3	840 355 16	A-209	1/1
4	840 355 16	A-210	1/1
5	352 800 16	A-011	1/1
6	376 824 3	A-610	1/1


4x	s1	4x	s2	30x	l1	2x	d1	2x	p26	6x	p54
4x	r1	4x	r16	4x	p25	1x	m1	1x	m1	4x	k43
2x	a143	2x	b119	4x	e1	8x	f1	1x	z1	8x	p50




1




3



2



4



! a=b

