



Installation manual

Table: 110H



Element symbol	Dimensions		Code	Package
1	720	399	1 110H-1	1/1
2	866	150	1 110H-2	1/1
3	866	60	1 110H-3	1/1
4	900	400	1 110H-4	1/1
5	868	200	1 110H-5	1/1
6	720	399	1 110H-6	1/1
7	400	200	1 110H-7	1/1
8	200	200	1 110H-8	1/1
9	183	199	2 110H-9	1/1
10	148	200	1 110H-10	1/1

7x

f1

øx10 mm

1x

y1

ø12x20

1x

z1

ø12x20

16x

e1

ø12x20 mm

16x

s1

ø12x20 mm

12x

s2

ø12x20 mm

6x

k1

ø12x20 mm

12x

r16

ø12x20 mm

0

10

20

30

40

50

60

70

80


90

100


110

120


mm




1




3



2




4




5

I


7



6




L




5


11



7



6



R

