










Instalation manual

LORA:

HANGERS





No					
1	I-402	1200	250	16	3
2	I-403	848	250	16	1
3	I-404	800	90	16	1
4	I-405	800	90	16	2