




Installation manual

Jasmin




Element symbol	Dimensions			Code	Package
1	1700	415	16	1	J-201 1/3
2	1184	397	16	1	J-202 1/3
3	518	397	16	1	J-107 1/3
4	483	396	16	1	J-306 1/3
5	202	397	16	1	J-111 1/3
6	1004	415	16	1	J-203 1/3
7	780	250	16	1	J-305 1/3
8	300	397	16	1	J-109 1/3
9	518	413	16	1	J-108 1/3
10	1368	696	16	1	J-106 2/3
11	463	1004	16	1	J-101 2/3
12	270	250	16	1	J-110 2/3
13	270	250	16	1	J-103 2/3
14	578	250	16	2	J-302 2/3
15	312	1197	16	1	J-001 2/3
16	578	250	16	2	J-307 2/3
17	636	250	16	1	J-301 2/3
18	921	250	16	1	J-304 2/3
19	270	250	16	2	J-102 2/3
20	200	250	16	2	J-104 2/3
21	326	1193	3	1	J-601 2/3


1x m282.02	4x g2	8x e19	12x p18	6x	1x z1	4x p17	2x a144
35x e1	35x s1	30x l1	1x c235	2x p9	4x f3	4x p17	2x a144
10x r1	10x r16	10x s2	58x f1	10x p25	2x b119	4x p17	2x a144




1




3




2




4




5




7






6




8





11





12




9




10




13



15



14



16

