













Instalation manual

ARSAL: SZFK WISZ




Element symbol	Dimensions				Code	Package
1	1360	281	16	1	SZFK_WISZ.002	1/1
2	368	264	16	1	SZFK_WISZ.003	1/1
3	368	264	16	1	SZFK_WISZ.004	1/1
4	368	261	16	1	SZFK_WISZ.005	1/1
5	368	80	16	2	SZFK_WISZ.021	1/1
6	1434	318	16/48	1	SZFK_WISZ.001	1/1
7	386	1344	3	1	SZFK_WISZ.006	1/1





1**3****2****4**

5



7



6

⚠
a=b

