








Installation manual

HO_2S




Element symbol	Dimensions	Code	Package
1	1200	551	1 tabl_2S.001
2	727	550	1 tabl_2S.002
3	784	280	1 tabl_2S.003
4	366	514	1 tabl_2S.004
5	366	60	1 tabl_2S.005
6	727	550	1 tabl_2S.006
7	431	550	1 tabl_2S.007
8	366	514	1 tabl_2S.008
9	514	366	1 tabl_2S.009
10	326	502	2 tabl_2S.010
11	360	173	2 tabl_2S.011
12	500	110	2 tabl_2S.012
13	500	110	2 tabl_2S.013
14	308	110	2 tabl_2S.014


4x	k1	4x	p9	2x	c235	2x	L-450	4x	s1	4x	e1
1x	z1	25x	ø16	25x	r16	25x	ø15x12mm r16	42x	f1	24x	p25




1




3




2




4




7



8



5



6

