











Instalation manual
Lavenda: Table_160 Classic


Lavenda: Table 160 Classic




Element symbol	Dimensions			Code	Package
1	1600	900	70	1 L-222	1/4
2	734	120	16	2 L-421	3/4
3	734	120	16	2 L-422	3/4
4	734	120	16	2 L-423	3/4
5	734	120	16	2 L-424	3/4
6	100	586	16	2 L-425	2/4
7	100	1254	16	2 L-426	2/4




1




3




2





4



5



7



6

