








Instalation manual


SZAFKA RTV VERNE 2




Element symbol	Dimensions	Code	Package
1	1379	RTV_2S_vagonka.001	1/2
2	1313	RTV_2S_vagonka.002	1/2
3	1313	RTV_2S_vagonka.003	1/2
4	227	RTV_2S_vagonka.004	1/2
5	1313	RTV_2S_vagonka.005	1/2
6	186	RTV_2S_vagonka.006	1/2
7	591	RTV_2S_vagonka.007	1/2
8	400	RTV_2S_vagonka.008	1/2
9	400	RTV_2S_vagonka.009	1/2
10	489	RTV_2S_vagonka.012	1/2
11	489	RTV_2S_vagonka.013	1/2
12	454	RTV_2S_vagonka.014	1/2
13	609	RTV_2S_vagonka.015	1/2
14	652	RTV_2S_vagonka.018	2/2

2x		φ3x16 mm	n260.01.007	5x		k1
2x		L-400	400 mm	40x		y1
1x		z1	φ8x30 mm	24x		p25
30x		f1	φ3.5x16 mm	11		s1
30x		j8	φ4x25 mm	30x		e1
2x		r1	φ3.5x12 mm #16	4x		r16
2x		s2	22285	30x		s1







3



4




1




2


5




7



6





8




9



a=b



10



s1
e1
s1
e1

