









Instalation manual

SZAFKA RTV 140 INES 2




Element symbol	Dimensions	Code	Package
1	1379	RTV_2S_alyzi.001	1/2
2	1313	RTV_2S_alyzi.002	1/2
3	1313	RTV_2S_alyzi.003	1/2
4	652	RTV_2S_alyzi.004	2/2
5	652	RTV_2S_alyzi.005	2/2
6	227	RTV_2S_alyzi.006	1/2
7	1304	RTV_2S_alyzi.007	1/2
8	186	RTV_2S_alyzi.008	1/2
9	591	RTV_2S_alyzi.009	1/2
10	400	RTV_2S_alyzi.010	1/2
11	400	RTV_2S_alyzi.011	1/2
12	454	RTV_2S_alyzi.018	1/2
13	609	RTV_2S_alyzi.021	1/2
14	489	RTV_2S_alyzi.016	1/2
15	489	RTV_2S_alyzi.017	1/2


2x		$\phi 3 \times 16$ mm	p2	2x		n260.01.007	n260
2x		L-400	400 mm	40x		l1	l1
1x		z1	$\phi 8 \times 30$ mm	24x		p25	p25
30x		f1	$\phi 8 \times 30$ mm	30x		r1	r1
				10x		s1	s1
				10x		e1	e1
				2x		c175	c175
				2x		j8	j8
				2x		M4x25 mm	M4x25 mm
				5x		k1	k1
				30x		r16	r16
				30x		s2	s2




1




3




2




4




5




7



6



8



9

10

! a=b

